



Shelf-Attached Enclosure Panel 3-Sided Carts

Assembly Instructions

When you open the carton you will find: (1) one wire enclosure panel. It is either 13" wide or 19" wide with lengths of 63" or 72" depending on the post that was ordered.

To Install:

Step 1) Assemble the cart making certain that there is a shelf at the very top and a shelf at the bottom

Step 2) The panels have wires that form a hook at the top and prongs at the bottom. Press the panel against the cart sliding it down to allow the top hooks to capture the top shelf and the prongs at the bottom to slide behind the bottom shelf edge.

Which Panels Do I Use And Where?

For an 18" deep cart, you would use a 13" wide panel on each 18" side.

For a 24" deep cart, you would use a 19" wide panel on each 24" side.

For the shelf widths shown below, select panels for the back as shown:

36" = (3) 13" & (1) 19"

48" = (2) 13" & (2) 19"

60" = (3) 13" & (2) 19"

72" = (2) 13" & (4) 19"