



Post-Attached Enclosure Panel 3-Sided Carts

Assembly Instructions

How To Use Post-Attached Panels:

First, assemble the cart. Be sure to have the top shelf dropped down so you can use that shelf for storage!

Step 1 – Add back panels FIRST. Hang the top panel from the top of the cart, aligning the top loops over the post screw holes. Position the side wire prongs around the posts. Insert screws into holes and LOOSELY tighten as they will be removed in Step 3.

Step 2. Next, hang the bottom back panel from the top back panel, being sure to slide the wire prongs down inside the bottom shelf.

Step 3 – Then add end/side panel. Remove the screw from the post in back. Secure the bottom of the side panel to the cart by positioning the side wire prongs at the bottom of the panel around the side posts. Then hang the end panel from the top of the cart by aligning the top loops over the post screw holes, re-insert screws into holes and tighten.

Step 4 – Add the second end/side panel.